


Operating Manual Manual Coffee Grinder



Manual Coffee Grinder Fine wood / Fruit wood / Driftwood





- ① Ground coffee container
- 2 O-Ring
- **3** Coffee bean container
- 4 Cover (with O-Ring)
- 5 Hand crank
- 6 Knob
- ⑦ Adjustment wheel
- (8) Grinding mechanism
- ④ Grinding cone





Seemühlen-Manufaktur Manual Coffee Grinder with Ceramic Mechanism

Congratulations!

You have purchased a manual coffee grinder by Seemühlen-Manufaktur from Germany's Allgäu region. Our grinders are hand-crafted with local, well-seasoned fine and fruit woods as well as carefully-selected driftwood from the shores of Lake Constance.

Wood is a natural material which changes as it is influenced by the passing of time. Variations in temperature, humidity or light can influence colour shades or create small surface cracks, which can occur in spite of careful monitoring over years. Our driftwood grinders are especially prone to those changes.

Some wood has spent long periods of time in water, which causes the wood to lose some of its stability, while gaining texture and character. Poetically speaking: This wood displays the "beauty of imperfection"; we work to highlight that beauty.

Driftwood may feature a rough surface, indentations or surface cracks, which can increase or decrease over time. The grinding mechanism is not impacted by these features. It remains embedded in the grinder within a stable housing. Some cracks are deemed design elements and are highlighted with epoxy resin. At the end of the process all grinders are treated with natural wood waxes.

If you have selected a coffee grinder either of fruit wood or a fine wood version, these grinders will naturally also change Manual Coffee Grinder Fine wood / Fruit wood / Driftwood



over time, however, to a much reduced extent than driftwood grinders.

Our grinders are produced with a CrushGrind® ceramic conical grinder. The advantages are:

- simple adjustment for all types of coffee brewing
- consistent grinding results
- quick grinding and
- corrosion-free

Operating Instructions

Always adjust the grind setting without beans in the grinder, however, do not operate the grinder on the fine setting without beans in the grinder! Fill the unit simply by removing the hand crank (\mathfrak{F}) and the cover (\mathfrak{F}) beneath it - reverse the steps to close the unit and insert the handle to the stop.

The grind can be set with small clicks (0.03mm/click) on the adjustment wheel ⑦. Tighten the adjustment wheel completely, then release the wheel as you count the clicks.

| Clicks: | 4-9 | 10-15 | 16-21 | 22-26 | 27-32 | > 33 |
|--------------------|-------------------|----------|-------|-------|-----------------|------|
| Brewing Method: | Turkish Coffee | Espresso | Mokka | | French Press | |

Depending on your roasted coffee beans you will quickly find your ideal setting. Be certain that you do not turn the handle on the grinder while the adjustment wheel is completely closed - the ceramic grinder parts will be permanently damaged.



Caution! The hand crank is only inserted on the grinder, turning the grinder over will result in the handle falling out.

When turning the adjustment wheel 1 always keep some resistance on the hand crank 3. The same goes for taking apart the grinding mechanisim 8 for cleaning. See cleaning tips below.

Always clean out the ground coffee container container and remove any residual coffee grounds. Ideally with enclosed coffee brush, so no grounds remain, which could lead long-term to a negative off-taste in your brewed coffee. The ground coffee container and the cover are held in place by O-rings, which can wear out. O-rings and coffee brush bristles for replacement are included.

Cleaning Instructions

The exterior of the grinder (1,3) (4) and the handle knob (6) can best be cleaned with a soft damp cloth and then dried with a towel. From time to time the exterior can be treated with a hard furniture oil by applying a small amount with a soft cloth and then removing the excess oil.

Residual oils from the coffee beans can diminish the grinding function if allowed to remain. We recommend cleaning the grinder regularly with a coffee grinder cleaning granulate (e.g. Grindz Espresso Cleaner). The ceramic grinding mechanism can also be removed and cleaned in the dishwasher. Dismantle the adjustment wheel ⑦ and remove the grinding cone ⑨. Completely dry the parts before reassembly. The grinder is not dishwasher safe.

Manual Coffee Grinder Fine wood / Fruit wood / Driftwood



Additional tips and answers to frequent questions (FAQ) or video instructions can be found on our website at www.seemuehlen.de.

Warranty Services

Seemühlen-Manufaktur guarantees (under correct, normal use with coffee beans in private households in Germany) the problem-free functioning of the coffee grinder for five years from the date of purchase. In addition, the firm CrushGrind® guarantees all ceramic parts for twenty-five years. Our guarantee is that during the guarantee period we will repair or replace the defective grinding mechanism. Should you have problems with your coffee grinder, please return the grinder with your purchase receipt directly to your retail store or send it directly to us at the address below.

Guarantee Stipulations

There is no warranty coverage for damage that occurs as follows: not following the operating and maintenance instructions in this operation manual, inappropriate or improper usage, incorrect or careless use, any kind of force or striking (e.g. dropping on the floor or hitting with a hard object), mechanical, chemical or physical damage resulting from nonintended use. The guarantee lies solely in the gratis repair or exchange of the defective ceramic grinding mechanism by the guarantor and postage free shipping of the unit.



Customer Service

Your trust and satisfaction is important to us. If you have questions about our products, guarantee, or our repair service, please simply use the following contact information:

Telephone: +49 8321 2605810 E-Mail: support@seemuehlen.de Web: www.seemuehlen.de

We are also pleased to serve you and personally advise you at our main location in Germany's Allgäu: Seemühlen-Manufaktur Immenstädter Straße 13 87544 Blaichach Deutschland

Every Seemühlen purchase supports Seephilharmonie, the International Music Project on Lake Constance. Thank you very much! www.seephilharmonie.de