






Operating Manual
Salt & Pepper Mills

Salt & Pepper Mills
Fine wood / Fruit wood / Driftwood



Salt & Pepper Mills
Fine wood / Fruit wood / Driftwood



- ① **Rotary Handle**
- ② **Centering star** (only for large mills)
- ③ **Mill body**
- ④ **Mechanism** (in the lower part of the body)
- ⑤ **Adjustment wheel**
- ⑥ **Mechanism** (made of ceramic or steel)
- ⑦ **Adjustment spring**



Seemühlen-Manufaktur **Salt and pepper mills with quality grinders**

Congratulations!

You have purchased a manual coffee grinder by Seemühlen-Manufaktur from Germany's Allgäu region. Our grinders are hand-crafted with local, well-seasoned fine and fruit woods as well as carefully-selected driftwood from the shores of Lake Constance.

Wood is a natural material which changes as it is influenced by the passing of time. Variations in temperature, humidity or light can influence colour shades or create small surface cracks, which can occur in spite of careful monitoring over years. Our driftwood grinders are especially prone to those changes.

Some wood has spent long periods of time in water, which causes the wood to lose some of its stability, while gaining texture and character. Poetically speaking: This wood displays the "beauty of imperfection"; we work to highlight that beauty.

Driftwood may feature a rough surface, indentations or surface cracks, which can increase or decrease over time. The grinding mechanism is not impacted by these features. It remains embedded in the grinder within a stable housing. Some cracks are deemed design elements and are highlighted with epoxy resin. At the end of the process all grinders are treated with natural wood waxes.

If you have selected a coffee grinder either of fruit wood or a fine wood version, these grinders will naturally also change

over time, however, to a much reduced extent than driftwood mills.

Our grinders are equipped with either a ceramic or steel cone grinder. The advantages are:

- simple adjustment for all grinding degrees
- consistent grinding results
- quick grinding and
- corrosion-free
- a steel grinder with the highest cutting quality, ideal for pepper, guarantees the best aroma development,
- a ceramic grinder for salt, as it is absolutely corrosion-free.

Operating instructions

The grinding degree can be quickly adjusted with or without salt / pepper, but never grind finely without salt / pepper! To fill, simply pull the rotary handle ① upwards (possibly with a slight jerk) and then push it back on as far as it will go. When refitting, pay attention to the pentagon of the quick-release axle. Larger grinders contain a centering star in the grinder body through which the quick-release axle runs. This does not need to be removed when refilling.

The grinding degree can be finely adjusted. To do this, turn the adjustment wheel ③ to the left (coarser) or to the right (finer). Matching funnels and wooden coasters are also available as accessories.

Make sure that the grinder is not tightened! This would result in abrasion and damage to the grinder.

Our spice mills with galvanized nickel-plated steel grinders may only be used with pepper. Use with salt voids the guarantee!

Our spice mills with ceramic grinders are ideal for coarse-grained salt, but are also suitable for pepper and other spices. An overview of suitable spices can be found on our website under FAQ.

Cleaning Instructions

The exterior of the mill ① ③ ④ can best be cleaned with a soft damp cloth and then dried with a towel. From time to time the exterior can be treated with a hard furniture oil by applying a small amount with a soft cloth and then removing the excess oil.

We recommend cleaning the grinder regularly with rice. The ceramic grinding mechanism can also be removed and cleaned in the dishwasher. Dismantle the adjustment wheel ⑤ and remove the grinding cone ⑥. Completely dry the parts before reassembly. The grinder is not dishwasher safe.

Additional tips and answers to frequent questions (FAQ) or video instructions can be found on our website at www.seemuehlen.de.

Warranty Services

Seemuehlen-Manufaktur guarantees (under correct, normal use with salt or peppercorns in private households in Germany) the problem-free functioning of the coffee grinder for five years from the date of purchase. In addition, the firm CrushGrind® guarantees all ceramic parts for twenty-five years. Our guarantee is that during the guarantee period we will repair or replace the defective grinding mechanism. Should you have problems with your coffee grinder, please return the grinder with your purchase receipt directly to your retail store or send it directly to us at the address below.

Guarantee Stipulations

There is no warranty coverage for damage that occurs as follows: not following the operating and maintenance instructions in this operation manual, inappropriate or improper usage, incorrect or careless use, any kind of force or striking (e.g. dropping on the floor or hitting with a hard object), mechanical, chemical or physical damage resulting from non-intended use. The guarantee lies solely in the gratis repair or exchange of the defective ceramic grinding mechanism by the guarantor and postage free shipping of the unit.

Salt & Pepper Mills
Fine wood / Fruit wood / Driftwood



Customer Service

Your trust and satisfaction is important to us. If you have questions about our products, guarantee, or our repair service, please simply use the following contact information:

Telephone Office: +49 8321 2605810
WhatsApp: +49 170 5469320
E-Mail: support@seemuehlen.de
Web: www.seemuehlen.de

We are also pleased to serve you and personally advise you at our main location in Germany's Allgäu:

Seemühlen-Manufaktur
Immenstädter Straße 13
87544 Blaichach
Deutschland

Every Seemühlen purchase supports Seephilharmonie, the International Music Project on Lake Constance. Thank you very much! www.seephilharmonie.de